

CLACK Controller



TC – Controller

- up to nine preprogrammed regeneration cycles selectable
- time controlled
- metric units
- programmable times, preprogrammed cycles
- applicable for WS 1; WS 1.25 and WS 1.5
- two control levels
- manual regeneration start
- regeneration start by differential pressure
- for co - current regeneration



TVC – Controller

- 6 - cycle program preprogrammed
- free programmable times, cycles preprogrammed
- optional as time or volume controlled
- metric units
- applicable for WS 1; WS 1.25 and WS 1.5
- manuelle Regenerationsauslösung
- two control levels
- manual regeneration start
- regeneration start by differential pressure
- for co - current regeneration



CI – Controller

- 9 cycles free programmable
- times free programmable
- for co-current and counter-co-regeneration
- metric or american units
- applicable for WS 1; WS 1.25 and WS 1.5
- four control levels
- manual regeneration start
- regeneration start by differential pressure-
- maintenance and history information